


Raychem


CE20-01

CE20-03

0 10 20 30 40 50 60 70 80 90 100 110 120 130 140 150 160 170 180 190 200

A





*CE20-03 only

B**C**

HWAT-L
 HWAT-M
 HWAT-R → CE25-01

Aluminium


FS-A-2X
 FS-B-2X
 FS-C-2X
 GM-2X
 FroStop Black
 FroStop Green
 LC2-10-CR
 FreezeGard-W32
 FreezeGard-W52
 R-ETL-A





HWAT-L/-M

4




FS-A-2X
FS-B-2X
FS-C-2X
GM-2X


FroStop Black
FroStop Green
LC2-10-CR
FreezeGard-W32

FreezeGard-W52
HWAT-L
HWAT-M
ETL-A


5




6




7




8




9



10




CE20-03 → 20




CE20-01

11→19

11



12






HWAT-L/-M

13

13



HWAT-L/-M



FS-A-2X
FS-B-2X
FS-C-2X


GM-2X
FroStop Black
FroStop Green

HWAT-L
HWAT-M


14

14


40 mm




15




16




17







18




19







23




24




25



26



27



België / Belgique

Tyco Thermal Controls
Staatsbaan 4A
3210 Lubbeek
Tel. 016 21 35 02
Fax 016 21 36 04

Česká Republika

Raychem HTS s.r.o.
Novodvorská 82
14200 Praha 4
Tel. 241 009 215
Fax 241 009 219

Danmark

Tyco Thermal Controls Nordic AB
Stationsvägen 4
S-430 63 Hindås
Tel. 70 11 04 00
Fax 70 11 04 01

Deutschland

Tyco Thermal Controls GmbH
Englerstraße 11
69126 Heidelberg
Tel. 0800 1818205
Fax 0800 1818204

France

Tyco Thermal Controls SA
B.P. 90738
95004 Cergy-Pontoise Cedex
Tél. 0800 906045
Fax 0800 906003

Italia

Tyco Electronics Raychem SPA
Centro Direzionale Milanofiori
Palazzo E5
20090 Assago, Milano
Tel. 57 57 61
Fax 57 57 6201

Nederland

Tyco Thermal Controls b.v.
Van Heuven Goedhartlaan 121
1181 KK Amstelveen
Tel. 0800 0224978
Fax 0800 0224993

Norge

Tyco Thermal Controls Norway AS
Postboks 6076 - Etterstad
0601 Oslo
Tel. 66 81 79 90
Fax 66 80 83 92

Österreich

Tyco Thermal Controls
Office Wien
Brown-Boveri Strasse 6/14
2351 Wiener Neudorf
Tel. 0 22 36 86 00 77
Fax 0 22 36 86 00 77-5

Polska

Tyco Thermal Controls Polska Sp. z o.o.
ul. Cybernetyki 19
02-677 Warszawa
Tel. +48 22 331 29 50
Fax +48 22 331 29 51

Schweiz / Suisse

Tyco Thermal Controls N.V.
Office Baar
Haldenstrasse 5
Postfach 2724
6342 Baar
Tel. 041 766 30 80
Fax 041 766 30 81

Suomi

Tyco Thermal Controls Nordic AB
Flöjelbergsgatan 20B
S-431 37 Mölndal
Puh. 0800 11 67 99
Telekopio 0800 11 86 74

Sverige

Tyco Thermal Controls Nordic AB
Flöjelbergsgatan 20B
431 37 Mölndal
Tel. 020-210 100
Fax 031-335 58 99

United Kingdom

Tyco Thermal Controls (UK) Ltd
3 Rutherford Road,
Stephenson Industrial Estate
Washington,
Tyne & Wear
NE37 3HX
Tel. 0800 969013
Fax: 0800 968624

tyco

Thermal Controlswww.tycothermal.com